

CLASSROOM AV CONTROL SYSTEM OPERATION MANUAL

INDEX

1. System Power-On	3
2. Overview	4
3. Table Box	6
4. Source Page	7
5. Notebook VGA	8
6. Notebook HDMI	10
7. Desktop	12
8. BLU-RAY Player	14
9. Visualizer Operation	16
10. Visualizer Selection	18
11. Table Video AUX	20
12. External VGA	22
13. Controls	23
14. Media Volume Control	24
15. Microphone Volume Control	25
16. BLU-RAY Player Control	26
17. Projector Control	27
18. Screen Control	29

OPERATION MANUAL - POWER ON SYSTEM



Switch language
CHINESE / ENGLISH

Press the "SYSTEM ON" button to turn on the AV system and it takes 5 seconds.

OPERATION MANUAL - OVERVIEW



POWER OFF

OPERATION MANUAL - OVERVIEW


Navigation Tab contains 3 pages: [Source](#), [Controls](#) and [Screen](#).



SOURCE



CONTROLS



SCREEN


OPERATION MANUAL - TABLE BOX

Open the Table Box to get the appropriate cables.

NOTEBOOK HDMI
CABLE

NOTEBOOK VGA AND
AUDIO CABLE

TABLE VIDEO AUX
CABLE



OPERATION MANUAL - SOURCE PAGE

Source Page contains 2 pages.

Page 1



NEXT PAGE

Page 2



PREVIOUS PAGE

OPERATION MANUAL - NOTEBOOK VGA


Step 1

Connect the VGA cable on the desk to your notebook.



Step 2

Press the "Notebook VGA" button.



OPERATION MANUAL - NOTEBOOK VGA

Step 3

Press the appropriate button to select the projector, then press the  to confirm.



Step 4

Press the appropriate function keys on your notebook for image output. The function keys locate among F1 - F12, on which there is a monitor icon or the words "CRT/LCD".



OPERATION MANUAL - NOTEBOOK HDMI


Step 1

Connect the HDMI cable on the desk to your notebook.



Step 2

Press the "Notebook HDMI" button.



OPERATION MANUAL - NOTEBOOK (HDMI)

Step 3

Press the appropriate button to select the projector, then press the  button to confirm.



Step 4

Press the appropriate function keys on your notebook for image output. The function keys locate among F1 - F12, on which there is a monitor icon or the words "CRT/LCD".



OPERATION MANUAL - DESKTOP

Step 1

Turn on Desktop PC by pressing the "Power ON" button on desktop.



Step 2

Press the "DESKTOP" button.



OPERATION MANUAL - DESKTOP

Step 3

Press the appropriate button to select the projector, then press the  button to confirm.



OPERATION MANUAL - BLU-RAY PLAYER

Step 1

Turn on the BLU-RAY player by pressing the "ON/STANDBY" button.



Press  button to open or close disk tray.

Step 2

Press the "BLU-RAY" button.



OPERATION MANUAL - BLU-RAY PLAYER

Step 3


Press the appropriate button to select the projector, then press the  to confirm.



Step 4

System will direct to BLU-RAY player control page automatically.

Press to show page 1




Press to show page 2



OPERATION MANUAL - VISUALIZER OPERATION


POWER ON

Turn on the visualizer by pressing the "ON/OFF" button.



LED LAMP



Press the "Lamp Switch" button to change the LED lamp status: bright, dim, and off.



OPERATION MANUAL - VISUALIZER OPERATION

AUTO FOCUS


Press the "Focus" button to auto focus.



ZOOM IN / OUT

The display range of the document can be adjusted by pressing the "Zoom In" and "Zoom Out" buttons.


Zoom



OPERATION MANUAL - VISUALIZER SELECTION

Step 1

Turn on the visualizer by pressing the "ON/OFF" button.



Step 2

Press the "VISUALIZER" button.



OPERATION MANUAL - VISUALIZER SELECTION

Step 3

Press the appropriate button to select the projector, then press the  button to confirm.



OPERATION MANUAL - TABLE AUX

Table AUX is for external devices, such as VCR or portable sound systems, to connect the classroom AV system.

Step 1

Connect the RCA cable on the desk to your external device.



Step 2

Press the "TABLE AUX" button in Source Selection Page .



OPERATION MANUAL - TABLE AUX

Step 3

Press the appropriate button to select the projector, then press the  button to confirm.



OPERATION MANUAL - EXTERNAL VGA

Wall plate external VGA function is for external devices connect to classroom AV system.



External VGA

OPERATION MANUAL - CONTROLS

Controls Page contains 4 control functions:

Media Volume, MIC. Volume, BLU-RAY player and Projector.




Press to enter
Controls page

OPERATION MANUAL - MEDIA VOLUME CONTROL


Media Volume Control (Notebook, Table AUX, BLU-RAY Player, VGA AUX, VIDEO AUX).

Step 1

Press the "MEDIA VOLUME" button or "MEDIA VOLUME BAR".




OR



Step 2

"CONTROL FADER" determines the level of media volume.



VOLUME LEVEL

CONTROL FADER


MUTE / UNMUTE

RESET MEDIA
VOLUME LEVEL

OPERATION MANUAL - MICROPHONE VOLUME CONTROL


Step 1

Press the "MIC. VOLUME" button.



Step 2

"CONTROL FADER" determines the level of microphone volume.



VOLUME LEVEL


CONTROL FADER

RESET MIC. VOLUME
LEVEL

OPERATION MANUAL - BLU-RAY PLAYER CONTROL

Step 1

Press the "BLU-RAY PLAYER" button.



Step 2

BLU-RAY Player control page contains 2 pages.

Press to show page 1.




Press to show page 2.



OPERATION MANUAL - PROJECTOR CONTROL


Step 1

Press the "PROJECTOR" button.



Step 2

Press appropriate button to select projector.




OPERATION MANUAL - PROJECTOR CONTROL

Step 3

Press appropriate button to control projector picture.


Current projector
number



Mute /Unmute projector picture.



Auto adjust projector picture.




Change projector picture aspect ratio:
16:9, 4:3 and normal.

OPERATION MANUAL - SCREEN CONTROL

Step 1


Press "SCREEN" button in Navigation Tab to enter screen control page.

Press to enter
Screen Control
page



Step 2

Press appropriate button to control window curtain



OPERATION MANUAL - SCREEN CONTROL

Step 3

Press appropriate button to control screen.

Current
screen number

