Classroom AV Control Operation Guide

CMDO - CSS

SYSTEM ON



To activate the system, press this button and wait until it directs you to the main page



SYSTEM OFF

Press the POWER button on the lower right corner and then select ✓ to shut down the system



SOURCE SELECTION





Select icon of desired input source to transmit video signal to projector

* Only for use in clasroom equipped with "DESKTOP"



MULTIMEDIA CONTROL





Multimedia Volume Control Page



Microphone Volume Control Page



Blu-ray Player Control Page




Projector Control Page for display alignments



SCREEN CONTROL





Press Screen Control
Page, raise or lower the
screen on the Screen
Control Page



Please browse through our Campus Services Section (CSS) website for more operation guidelines



Report any problem by raising work order through Computerised Maintenance Management System (CMMS) (Use the University's Wi-Fi network)