

Classroom AV Control Operation Guide

MULTI PROJECTION

CMDO - CSS

SYSTEM ON




To activate the system, press this button and wait until it directs you to the main page



1

SOURCE SELECTION



Select icon of desired input source to transmit video signal to projector



Choose the desired output projector and confirm your selection

*Only for use in classroom equipped with "DESKTOP" or "WIRELESS PRESENTATION"

2

MULTIMEDIA CONTROL



Multimedia Volume Control Page

Microphone Volume Control Page

Blu-ray Player Control Page

Projector Control Page for display alignments



Select desired projector for display alignments



Please browse through our Campus Services Section (CSS) website for more operation guidelines





Report any problem by raising work order through Computerised Maintenance Management System (CMMS) (Use the University's Wi-Fi network)

SYSTEM OFF


Press the POWER button on the lower right corner and then select to shut down the system

3

SCREEN CONTROL



Choose the desired screen and confirm your selection



Press Screen Control Page, raise or lower the screen on the Screen Control Page