Classroom AV Control Operation Guide

Campus Services Section

SYSTEM ON

Welcome to UM classroom, please press the "SYSTEM ON" button to turn on the AV system.

SYSTEM ON

To activate the system, press this button and wait until it directs you to the main page

① SOURCE
② CONTROL
③ SCREEN
NOTEBOOK VGA
VISUALIZER
NOTEBOOK HDMI
BLU-RAY
④ POWER

SYSTEM OFF

Press the POWER button on the lower right corner and then select ✓ to shut down the system

1 SOURCE SELECTION

NOTEBOOK VGA NOTEBOOK HDMI VISUALIZER BLU-RAY

Select icon of desired input source to transmit video signal to projector

Select Projector
1 2
Confirm Cancel
Audio output followed by Screen 1.

Choose the desired output projector and confirm your selection.

Subject to the setup there may be more sources for selection

2 MULTIMEDIA CONTROL

MEDIA VOLUME
MIC. VOLUME
BLU-RAY PLAYER
PROJECTOR

Multimedia Volume Control Page

Microphone Volume Control Page

Blu-ray Player Control Page

Projector Control Page for display alignments

Select Projector
1 2
Confirm Cancel
Audio output followed by Screen 1.

Select desired projector for display alignments

3 SCREEN CONTROL

UP STOP DOWN

UP STOP DOWN

Press Screen Control Page, raise or lower the screen on the Screen Control Page

---

Please browse through our Campus Services Section (CSS) website for more operation guidelines

Report any problem by raising work order through Computerised Maintenance Management System (CMMS)

V4.2